



FULL VERSION MANUAL

EXCEED 4R



Art. no 37982



PRODUCT OVERVIEW

The Exceed 4R packaging contains the following parts:

- Lamp unit
- Headband
- Cable guide (side)
- Rechargeable Li-Ion battery 3.5 Ah
- USB-C charge cable
- Battery holder (2.0 /3.5)
- Quick guide

BEFORE USE

BATTERY CHARGING

The battery needs to be charged before first use.

1. Located on the side of the battery pack is a USB-C connector. Attach the included USB charge cable to this USB-C connector.
2. Connect the USB connection to a wall outlet, computer or other standard USB connection.
3. On the battery, there are 5 LEDs showing battery status during charging:
 - Green light (all 5 LEDs) = battery is fully charged
 - Red light blinking = battery is charging

Charge time is approximately 4 hours.

Note! When the battery is fully charged the charger automatically switches to maintenance mode.
Note! Never leave a battery unattended during charging.

Exceed 4R is compatible with all Silva batteries with the same connector as on Exceed 4R battery. Note that the battery indication may not be accurate with other Silva batteries and that the battery won't fit the battery holder.

ADJUST THE HEADBAND

The headband is ergonomically shaped to give comfortable fit. Use the 2 buckle adjustments to fit it perfectly to your head. Attach the headlamp in the head bracket by sliding the headlamp foot into the snap-in socket.

To remove, slide the headlamp up and out of the bracket.

BATTERY CARRYING

The battery pack can be carried in multiple ways; for example on the headband by using the battery holder, in a pocket, backpack or on the waist by using the extension cable and cable guide rear (not included), or mounted on the bike frame by using the Velcro strap (not included).

The ergonomic battery holder keeps the battery in place and improves the comfort when you carry the battery on your head. You attach the battery holder to the headband and then easily slide in the battery.

DURING USE


SILVA INTELLIGENT LIGHT AND FLOW LIGHT

Silva Intelligent Light optimizes the light pattern by the unique combination of a long reach spot light and a close flood light. With less head movements and a clear view of near as well as far obstacles, you gain the balance and confidence it takes to move fast and perform better. Our ingenious Silva Flow Light takes the optimization even further by providing seamless tuning of the light pattern for your favourite sport. Simply tilting the light downwards makes the beams wider to brighten up slower activities. When tilting the headlamp upwards, the light reaches longer to provide perfect vision when you move fast.

SWITCH ON YOUR HEADLAMP

A push button is located on the left side of the headlamp body. This button controls all light modes.

- To start the headlamp with Flow Light activated press push button with a short press.
- To start the headlamp with Flow Light deactivated press and hold push button for 1 second
- To cycle between the different modes use short presses.
- To turn the headlamp off press and hold button for 1 second



DEACTIVATED FLOW LIGHT

Flow Light deactivated means that the Light image will remain unchanged even if the headlamp is tilted up or down. This might be useful when the lamp is mounted on a helmet or a bike handle bar.

BOOST MODE

Exceed has a Boost mode that temporarily increases the light output to 2300 lumen during 10 seconds.

To enter Boost mode, do as follows:

- Switch headlamp ON (with Flow light activated or deactivated)
- Keep the power button pressed until headlamp turns OFF and keep pressing the button until the headlamp switches back ON.
- Headlamp has now entered Boost mode
- The light will remain in Boost mode for 10 seconds and then return to the light mode from where you entered Boost mode (for example MED)

Note! During the 10 seconds the headlamp is in Boost mode it is not possible to use power button.

TEMPERATURE CONTROL:

This headlamp might get hot. The headlamp temperature is depending on light mode, ambient air temperature and airflow (speed). Make sure to keep it away from children. Also, make sure it will not get in contact with sensitive or flammable material.

NOTE: Always make sure to disconnect the battery when the lamp is not in use.

Why does the light dim down for no apparent reason?

If the cooling is not sufficient, for instance if used while standing still, indoors or in high temperatures, then the light will automatically be reduced until acceptable surface temperature on the lamp body is reached. This means that the lower the ambient temperature, the stronger the light output.

BATTERY STATUS INDICATION

When battery is connected and the headlamp is switched on - the current battery status will automatically be visible for 30 seconds. To check battery status during use, the headlamp has to be switched OFF and then back ON again.

- 5 green LEDs = Fully charged
- 4 green LEDs = 80% of the battery remains
- 3 green LEDs = 60% of the battery remains
- 2 green LEDs = 40% of the battery remains
- 1 red LED = 20% of the battery remains

To get as much power as possible out from your battery, keep it away from low temperatures during use.

LOW BATTERY WARNING

During operation of the headlamp there will be a low battery warning when 10% of the battery energy remains. This is done by flashing both LEDs for 1 second and repeated again after 5 seconds.

RESERVE MODE

During operation, the lamp will go into reserve mode when there is 10% power left of the battery. All LEDs will flash before the lamp goes into this mode. Reserve mode can be overridden by pressing the button.

Warning: If you have pressed the button when headlamp is in reserve mode no more low battery warnings will appear before the headlamp turns OFF.



Visit: www.silva/environment
for more information about the
Waste Electrical and Electronic
Equipment (WEEE) Directive.



FULL VERSION MANUAL EXCEED 4R



Art. no 37982



AFTER USE

MAINTENANCE

To make sure you get maximum performance from your headlamp, clean it regularly with a damp cloth. Headband cleaning – rinse in warm water.

TECHNICAL SPECIFICATIONS:

| | |
|------------------------------------|----------------------|
| Weight headlamp including headset: | 129 g |
| Battery weight: | 129 g |
| Battery type: | Li-ion 7.4 V, 3.5 Ah |
| Light distance Max/Med/Min: | 220 m/120 m/40 m |
| Lumen Boost/Max/Med/Min: | 2300/2000/1000/80 |
| Burn time 20°C Max/Med/Min: | 4 h/6 h/20 h |
| Burn time -5°C Max/Med/Min: | 1 h/3 h/20 h |
| Reserve mode: | 0.5 h |
| Charging time: | 4 h |
| Water resistance: | IPX5 |
| Operative temperature range: | -20 - +60° |

ABOUT LI-ION BATTERIES

The battery should be stored in a dry environment within the temperature range of -20°C and +35°C.

If you would like to store your battery for a longer period (more than 30 days) the battery should not be fully charged. This may cause loss of its characteristics.

Li-ion batteries have a discharge rate of approx. 20% over a 30-day period. You can always charge a half full battery without damaging its characteristics.

Do not expose the battery for extreme temperatures which may cause fire or explosion. Do not disassemble or mistreat the battery; risk for chemical burn.

Keep away from children.

Do not dispose of batteries in fire. This may cause an explosion.

Do not submerge the batteries in water.

Do not short circuit the contacts.

Replace only with Silva batteries with the same connector as on Exceed 4R battery.

PROTECTING THE ENVIRONMENT.

Headlamp, batteries and packaging are recyclable. Please dispose these items at designated recycling stations.

WARRANTY

Silva warrants that, for a period of two (2) years*, your Silva product will be substantially free of defects in materials and workmanship under normal use. Silva's liability under this warranty is limited to repairing or replacing the product. This limited warranty extends only to the original purchaser.

If the Product proves defective during the warranty period please contact the original point of purchase. Make sure to have your proof of purchase on hand when returning the product. Returns cannot be processed without the original proof of purchase. This warranty does not apply if the product has been altered, not been installed, operated, repaired, or maintained in accordance with instructions supplied by Silva, or has been subjected to abnormal physical or electrical stress, misuse, negligence or accident. Neither does the warranty cover normal wear and tear. Silva is not responsible for any consequences, direct or indirect, or damage resultant from use of this product. In no event will Silva's liability exceed the amount paid by you for the product. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty is valid and may be processed only in the country of purchase.

* Batteries: one (1) year

For more information please visit www.silva.se

| | True Lumen ANSI | Burn Time -5°C ANSI | Burn Time +20°C ANSI | Light distance ANSI |
|----------|-----------------|---------------------|----------------------|---------------------|
| MAX MODE | 2000 lm | 1 h | 4 h | 220 m / 722 ft |
| MED MODE | 1000 lm | 3 h | 6 h | 120 m / 395 ft |
| MIN MODE | 80 lm | 20 h | 20 h | 40 m / 131 ft |

All values are measured and specified according to the
ANSI FL1 STANDARD

Lumen values show actual light output after 30 seconds
ANSI burn time is measured from power-on until lumen reaches <10%



Visit: www.silva/environment
for more information about the
Waste Electrical and Electronic
Equipment (WEEE) Directive.